

---

Subject: Crossover frequencies

Posted by [Wayne Parham](#) on Sun, 11 Mar 2007 19:16:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I try to keep crossover out of the 200Hz to 2kHz range as much as possible. Since many of my two-way designs use DI matching of a direct radiator to a horn, and since this requires crossover between 1kHz and 2kHz, I compromise and crossover at 1.6kHz. I've gone as low as 1.2kHz but don't like going down further, which is why I avoid 1kHz crossovers. Similarly, with three-ways, it's very tempting to compromise the woofer-to-midrange crossover point from 200Hz up to 500Hz or 600Hz on the woofer-to-midrange point, since that makes choices for midrange drivers so much more plentiful. You can go with a smaller driver if the crossover point is moved up. Horns get way smaller if you move up in frequency. But I just don't like the sound of speakers crossed over between 500Hz and 1kHz. Seems there's no getting around it, so I prefer to keep as much of the 200Hz to 2kHz range as possible covered by a single driver.

---