

---

Subject: Re: Cabinets for Four Pi speakers - now Crossovers  
Posted by [Wayne Parham](#) on Sun, 12 Apr 2009 05:30:48 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I use air core coils where possible to prevent saturation, but usually use laminated cores for coils larger than 3mH. An air core coil with enough meat to keep DC resistance down is just too large for the higher inductance values. If you look through the crossovers shown in the shopping cart, you'll notice that we put Erse Super-Q coils on some of them.

About resistors, I use a 100 watt part for the Zobel but 10 or 12 watt parts for the other locations. The R1/R2 values are made with a series/parallel network of four resistors to increase thermal limits.

The post below has links about various topics related to some of the things you've brought up such as L-Pads, choice of crossover components, etc.  
Tweeter circuits for constant directivity horns and waveguides

---