
Subject: Re: 3 Pi Build

Posted by [Wayne Parham](#) on Sun, 30 May 2010 16:09:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

Something is not right. This model is one of the smoothest of the line. You didn't say what horn you were using, but remember that these designs are specific to the parts called out in the plans. You can't necessarily substitute parts without design changes being required.

If you've built to spec, you can see a measurement of the same loudspeaker you are building here:

Crossover optimization for DI-matched two-way speakers Click on the "Vertical Nulls" link and you'll see the loudspeaker being measured on a S&L WTPro system. The screen shown is a measurement in real-time, scale is 10dB per division. The response chart is ruler-flat, with the only anomalies being down low, a result of room modes.

What measurement system are you using? How is it setup and in what environment? What microphone do you use? From what you said, I think you're using an RTA indoors with white noise. If the system isn't calibrated for the microphone, it may not be flat. I am using S&L and LMS with calibrated microphones and seeing the response shown in the video above.

Microphone calibration Lets look at the crossover and double-check it too. Obviously make sure the coils and capacitors are in their proper positions, that you didn't accidentally swap L1 and L2, for example, using the 1.0mH in the 1.5mH spot or something like that. The right positions are L1=1.0mH (tweeter circuit), L2=1.5mH (woofer circuit) and the tweeter capacitors are C1=0.47uF, C2=6.8uF and C3=20uF. The woofer circuit has a 20uF capacitor in position C4 and no Zobel.

block of R1 and R2 components in-circuit, just to be sure their values are right.

R1/R2 values don't just set attenuation and provide top-octave compensation but they also set the amplitude of the shelf around 2kHz. You can manipulate R1/R2 values to get any amount of output you want in these three areas, semi-independently:

1. overall attenuation (move the whole curve up or down without changing its shape)
2. top-octave boost (increase or decrease the level of the diagonal line up high)
3. bottom shelf amplitude (raise or lower the bottom region between about 2kHz and 5kHz)

The values of R1 and R2 are carefully balanced to provide not only attenuation and top octave CD equalization but also to provide a precise amount of damping of the core splitter filter. This sets the response in the ~2kHz region, setting that initial shelf. Increase damping reduces amplitude around 2kHz, and less damping increases output. This region immediately above crossover is set by damping and is irrespective of the response curve higher up. That's the whole approach of the

Constant directivity, compression drivers and crossovers
