

---

Subject: and with Damir's fine drawing...

Posted by [PakProtector](#) on Sat, 16 Apr 2005 23:46:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

One can test in-circuit. Attach the + lead to either A or B( the same thing circuit-wise ), and the - end to ground, and set meter to mA of current. \*\*\*\*check the safety fuse in the meter first. If it's blown, you won't get a reading.\*\*\*the bias LED's will go out. All the regulated current will bypass the amplifier triode through the meter.regards,Douglas

---