

---

Subject: Re: Some questions on Power supplies  
Posted by [Manualblock](#) on Mon, 28 Nov 2005 03:05:43 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Guys; I see that the 6v6 will not work with 750vct trans since it needs 350v plate voltage. 6l6 can get by with 300vplate voltage which should work with 750vct. But I wonder what effect a different rec tube would have. Say a 5u4 which should be able to pass greater current to the filter; no?Thats the kind of speculation I am interested in. Ie; If you find a rectifier circuit that will provide 300 volts on the plate with 150ma current. What changes will occur with the use of different rec tubes?What is the best way to rectify AC if you need a cap input or a choke input. Doesn't the type of rectifier tube affect the performance of the filter and how much benefit you gain with using a clc or lc filter?I can run the specs through PSUD II but I am looking more for a theoretical opinion of how to implement the different types of filters/the way to combine rec tube types with CLC or LC ladder filters. In reading different analysis of PS types there are some universal aspects of design that people apply to circuits in specific circumstances. Example: LC filters should be used in applications where there are wide variations in load current.Output voltage decreases with increasing current in the LC filter.These are the types of information that can frame the choices available to the builder. By expressing these simple truths it makes it much easier to begin the design process for a novice.When you guys start out with the maths and the design programs; those types of facts seem to get lost to the beginner.Is this helpfull at all?

---