
Subject: Vas calculator

Posted by [hitsware](#) on Sun, 04 Jan 2009 03:54:06 GMT

[View Forum Message](#) <> [Reply to Message](#)

Wayne, Would you tell me again the formula for the Vas calculator ?

Subject: Re: Vas calculator

Posted by [Wayne Parham](#) on Sun, 04 Jan 2009 05:46:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

Here 'tis: T/S Measurements

Subject: Re: Vad calculator

Posted by [hitsware](#) on Sun, 04 Jan 2009 16:03:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

Thank You, but I mean the one from your VadCalc calculator....

Subject: Electro-mechanical formulas (Thiele / Small)

Posted by [Wayne Parham](#) on Mon, 05 Jan 2009 00:31:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

I stopped maintaining the VadCalc applet. It was written in a weird little language called CA Realizer (Computer Associates), which I also used to write tubing movement programs for the oil and gas industry. I do most of my programming in C++, but that language was easier to use for some things, so I gave it a go for a while. I assume you want to use it because you don't want to build a box to find Vas with the sealed box method. If that's the case, I suggest the added mass method. Then again, I understand the desire to have a method that works without two impedance sweeps. The VadCalc process was simple to do, and provided a pretty good estimate of Vas. Here's a formula that you can use to calculate Vas, knowing efficiency η_0 , Q_{es} and f_s : More woofers specs list the SPL output at 1W/1M than reference efficiency, so here's a converter: These days, I use Keith Larson's Woofer Tester and Speaker Tester products. They really make life easier. It has evolved a long way since the original Woofer Tester that he used to sell through Parts Express. You can use it to do acoustic measurements and make a digital crossover using Spice models to simulate passive crossovers. It's a great tool. And it still does the T/S measurements. Smith & Larson Audio! If you want to find T/S specs making measurements manually, or if you want to calculate values from other known values, here's a list of formulas that

constantSpeaker total Q at fsEfficiency/bandwidth productResonant frequencyElectrical QSystem resonant frequencySystem total Q at fcResonant frequencySpeaker total Q at fsHalf power frequency (-3dB point)System resonant frequencyInternal box volumeComplianceFree air reference efficiencySpeaker resonant frequencyComplianceSpeaker electrical QSound pressure levelFree air reference efficiencyMaximum air volume displaced by cone excursionPeak linear displacementDiaphragm radiating areaVolume displaced at XmaxDiaphragm effective radiating diameterDiaphragm radiating areaK1 constantAir densitySystem resonant frequencyVolume displaced at XmaxSpeed of soundK2 constantK1 constantAmax constantMaximum displacement limited power outputK1 constantAmax constantRequired electrical input to achieve ParMaximum displacement limited power outputFree air reference efficiencyPeak sound pressure levelMaximum power input

Subject: Hyper Thanks : :)

Posted by [hitsware](#) on Mon, 05 Jan 2009 02:47:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

I have a Woofer Tester for drivers in hand, but am trying to develop a crude system for deriving ballpark T/S (Fs, Qts, Vas) parameters from the data given by ceiling speaker makers. For instance: <http://www.miscospeakers.com/Upload/pdf/KC620W-B%20Lit.pdf> http://www.quamspeakers.com/documents/techspec/QUAM_0201_8C10FECO.pdf Obviously the first has more to work with. Unfortunately the second is more typical.

Subject: Re: Hyper Thanks : :)

Posted by [Wayne Parham](#) on Mon, 05 Jan 2009 17:40:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

Yeah, I see your problem. Reminds me of driver specs in the 1970's.

Subject: Re: Electro-mechanical formulas (Thiele / Small)

Posted by [Wayne-o](#) on Mon, 19 Jan 2009 04:52:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

What's reference efficiency compared to the spl 1 watt 1 meter ? THANKS

Subject: Re: Electro-mechanical formulas (Thiele / Small)

Posted by [Wayne Parham](#) on Mon, 19 Jan 2009 05:44:44 GMT
[View Forum Message](#) <> [Reply to Message](#)

Sensitivity (decibels @ 1W/1M) where
