
Subject: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Damir](#) on Mon, 25 Jul 2005 20:01:05 GMT
[View Forum Message](#) <> [Reply to Message](#)

Reading the specs for some "Partridge" SE OPTs, I found something that can be interesting (if you like OPTs and math and have nothing better to do). The specs say: "Primary impedance $R_{pr}=3500$ Ohms, and four secondaries of 1 Ohms - for 4, 8 & 16 Ohms connection." How? We have turns ratio between the primary, N_{pr} (number of turns of the primary winding), and four identical secondaries $N_{s1}=N_{s2}=N_{s3}=N_{s4}$ $n = N_{pr} / N_{s1-4}$ We don't have those numbers, but we know impedance ratio(s): $z = R_{pr}/R_{sec1-4} = 3500/1 = 3500$ And from imp. ratio, our turns ratio is: $n = z^{0.5} = 3500^{0.5} = 59,16$ Note that $z^{0.5}$ is the square root of z . Simplified, we can "assume" that $N_{pr}=5916$ turns, and $N_{s1-4}=100$ turns. a) We can connect all four 1-Ohm secondaries in series: Then we have $n1=N_{pr}/(N_{s1}+N_{s2}+N_{s3}+N_{s4})= 5916/400 = 14,79$ And $R_{s-a} = R_{pr}/n1^2 = 3500/14,79^2 = 16$ Ohms b) We can connect only three secondaries in series, then we have $n2=N_{pr}/(N_{s1}+N_{s2}+N_{s3})=5916/300 = 19,72$ $R_{s-b} = R_{pr}/n2^2 = 3500/19,72^2 = 9$ Ohms ("close enough" to nominal 8 Ohms) c) We can connect only two secondaries in series (but probably, better to connect N_{s1} & N_{s2} in series, then N_{s3} & N_{s4} in series too, then both series "combinations" in parallel) $n3=N_{pr}/(N_{s1}+N_{s2}) = 5916/200 = 29,58$ $R_{s-c} = R_{pr}/n3 = 3500/29,58^2 = 4$ Ohms Simple enough, when we know what is impedance ratio (z), and what is turns ratio (n). Turns ratio is equal to voltage ratio, and if we measure, say, 100Vrms across the primary, and say, 5Vrms on 4-Ohms winding, we have voltage/turns ratio $=100/5 = 20$, and our impedance ratio is $z=n^2 = 20^2 = 400$. Then our primary impedance is $R_{pr} = z * R_{sec} = 400 * 4 = 1600$ Ohms.

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Thermionic](#) on Mon, 25 Jul 2005 20:38:56 GMT
[View Forum Message](#) <> [Reply to Message](#)

Interesting. Indeed, four 1 ohm secondaries in series do NOT make for 4 ohms, as the impedance ratio is the square of the winding ratio, instead of merely the sum of their individual reflected impedances added. Great post as usual, Damir! I know that some hi-end transformer makers, such as Plitron and Electra Print, use multiple secondaries tied together to attain a single, fixed value, usually around 5 or 6 ohms reflected Z. The fixed "middle of the road" value is intended to cover both 4 and 8 ohm speaker duties. They claim that better bandwidth is attained by this method. Thermionic

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Manualblock](#) on Mon, 25 Jul 2005 22:01:26 GMT
[View Forum Message](#) <> [Reply to Message](#)

How come the reflected Z doesn't change with frequency? Please excuse if this is a dumb question.

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [chana](#) on Tue, 26 Jul 2005 01:34:09 GMT
[View Forum Message](#) <> [Reply to Message](#)

all in series =16 Ohms all parallel = 4 Ohms two of them parallel then series to the other two =8 Ohms

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Damir](#) on Tue, 26 Jul 2005 04:43:11 GMT
[View Forum Message](#) <> [Reply to Message](#)

And how four identical 1-Ohm windings connected parallel become 4-Ohms secondary? The same for your 8-Ohms example. Can you post your math? Impedance (z) and turns ratio (n) are different things, $z=n^2$ - that's why I posted it, some people are little confused...

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Damir](#) on Tue, 26 Jul 2005 10:54:45 GMT
[View Forum Message](#) <> [Reply to Message](#)

Not dumb, we know that impedance of the speaker is not a constant resistor, but it changes with frequency. Properties of the OPT (Lp - bass frequencies, Lw & Cw high frequencies, etc.), and tube(s) connected (rp) also impact the frequency response. But, simplified - we can observe speaker like resistor, and primary load Ra like constant resistance, 3,5kOhms in this example, on some "middle" frequencies of interest.

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Damir](#) on Tue, 26 Jul 2005 11:00:26 GMT
[View Forum Message](#) <> [Reply to Message](#)

Thanks, and yes, my Plitron/Amplimo toroidal OPTs are 5 Ohms nominal secondary impedance. They have 5 secondaries, connected in parallel. But how they actually wound them (interleaving,

etc.) is the "secret" inside the potted unit...:-)

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Thermionic](#) on Tue, 26 Jul 2005 16:53:03 GMT
[View Forum Message](#) <> [Reply to Message](#)

Yep, I've had the pleasure of making the acquaintance of a few Plitrons myself, both PP (5 ohms nominal) and SE (4 and 8 ohms). That's how I knew about the multiple secondaries; the huge bundle of blue wires emerging from the potting epoxy that keeps the contents "top secret." I peel off the little silver "Designed by Vanderveen" stickers from the bottom and stick them on my toolbox for "victory marks," LOL!IMO, they're just about the best iron mankind has ever made. I have some Tamuras that are certainly quite detailed, coherent, and refined, but the Plitrons do eat their lunch, IMHO. Thermionic

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [Damir](#) on Tue, 26 Jul 2005 19:31:07 GMT
[View Forum Message](#) <> [Reply to Message](#)

I only wish that those OPTs are little less expensive...:-)Did you see that M. Vanderveen has www page now, mostly about R&D and consultation, but have some pages about new book, etc. BTW, his book "Modern High-End Valve Amplifiers" is IMO a new "standard" about OPTs and tube amps, I could only wish 100 more pages about amplifiers, classes of operations, etc. I learned much from his books, and from books by M. Jones, too. Hehe, "Tube Books" is a new message here...:-)
<http://www.mennovanderveen.nl/eng/>

Subject: Re: 4 x 1 Ohm = 16 Ohms (sometimes)
Posted by [chana](#) on Wed, 27 Jul 2005 22:27:36 GMT
[View Forum Message](#) <> [Reply to Message](#)

Sorry, I made a mistake on 4 ohms tap. It should be two pairs of 1 ohm parallel then connect two of them in series. Thanks
