
Subject: Pi 3 subwoofer

Posted by [48h350](#) on Mon, 09 Jul 2012 11:37:25 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Wayne, you sent me the plans for the Pi 3 sub.

Unfortunately the shipping to Australia is just about as expensive as the driver-Eminence Lab 12-itself, so i am looking for alternatives.

You did approve, in the past,the use of a car sub from JBL: GTO 1214 TD .

So I am thinking of using this driver to build the subs (2)

<http://www.jbl.com/resources/Brands/jbl/Products/ProductRelatedDocuments/en-US/BoxesandParameters/GTO1214TD.pdf>

I found this piece of software to work out dimensions,port length etc.

http://www.ajdesigner.com/fl_subwoofer/subwoofer.php

Is this software good enough to design the enclosure or would you use something else?

What alignment would you recommend?

Would you build a sub just as wide as the Pi 4 and use it as a stand?

Thanks for your work.

Massimo

Subject: Re: Pi 3 subwoofer

Posted by [Wayne Parham](#) on Mon, 09 Jul 2012 13:08:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

Subs are pretty easy to design, really. They don't have to run midrange frequencies, so there are no standing waves inside because the box is acoustically small. So you can expect the box modeling software to be accurate.

I like to use an alignment that is slightly overdamped so it doesn't become peaky when the voice coil gets hot.

Subject: Re: Pi 3 subwoofer

Posted by [48h350](#) on Thu, 12 Jul 2012 23:30:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Wayne I am following the road of using Palign to model the enclosure of the above mentioned driver jbl gto1214.

(Thiele and Small parameters attached in original post)

after a while I "think" I understand how to use it. Can I confirm with you that, to get QD for your program, you do: $Qd = 1/Qm + 1/Qe$?

where Q_m is Mechanical Q of the driver and Q_e is the electrical Q.
I obtained a Q_d of 2.133

I attach the results, can you be so kind to see if they make sense?

For the dimensions, am I right to assume that volume HAS to be reached with the suggested dimension in relation with the port diameter and length ? In other words if I wanted a square faced SW, is there any way to "lead" the program to do so ?

Thanks Wayne

massimo

File Attachments

1) [JBL GTO1.PID](#), downloaded 251 times

Subject: Re: Pi 3 subwoofer

Posted by [Wayne Parham](#) on Fri, 13 Jul 2012 01:09:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

Your results look good, and you could expect a nice little subwoofer from that 1ft³ box. It isn't very large and yet has 35Hz f₃ and 22Hz f₁₀. Port area is 12in², so you can make it 3.5" square and 5" long.

That woofer is suitable in tiny little boxes from 0.5ft³ up to about 3ft³. Helmholtz frequency should be 20-25Hz.

I'd probably put it in a box between 1ft³ and 2ft³ with Helmholtz frequency of 22Hz. It will work well in cabinets that size range.

Subject: Re: Pi 3 subwoofer

Posted by [48h350](#) on Fri, 13 Jul 2012 02:37:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

Great Wayne, thanks for that.

How can I get your software to work with a different volume?

Am I right to assume the pialign will only give a pi aligned result and one only?

So if I chose to build a box say 15"x 15" x 15" can I still use the 12sq. inches port and 5" long?

Thanks for your patience

massimo

Subject: Helmholtz formula

Posted by [Wayne Parham](#) on Fri, 13 Jul 2012 03:11:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

15" x 15" x 15" would be a nice box size for that woofer.

But PiAlign won't calculate a port for that box. It was designed to recommend a cabinet size, used mostly for mains cabinets really. It's literally a 1970s program. Not that electro-mechanical alignment software is or even needs to be more modern than that, but still, my point is that is a single-purpose design tool.

You could calculate the port using standard Helmholtz formula. That will be plenty for a sub, no need to do any more analysis.

Subtract the volume displaced by the driver and wood thickness. Without offset, a 15" x 15" a 15" box is 3375in³. If you use 3/4" wood, that will reduce it by about 9003 to ~2450in³. Estimate the volume offset by the woofer at 250in³. That leaves volume at ~2200in³. So calculate Helmholtz frequency using that volume, using the formula below:

Here's a little BASIC program that will calculate the formulas for you:

```
10 INPUT"Enclosure Volume";VE
20 INPUT"Diameter of Port";PD
30 INPUT"Length of Port";PL
40 VB=VE*1728:PI=3.1415926535:AP=PI*((PD/2)^2):LC=PL+((8*PD)/(3*PI))
50 FR=(13548/(2*PI))*(AP/(VB*LC))^.5
60 PRINT"Fr =";FR;"Hz."
70 GOTO 10
```

You can verify the Helmholtz frequency if you wish. Measure impedance and look for the minimum between the peaks to find the Helmholtz frequency.

Subject: Re: Helmholtz formula

Posted by [48h350](#) on Fri, 13 Jul 2012 04:17:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

Great.

I get 8.4 inches long port with a diameter of 4 inches in a 15"x15"x15" box with a Helmholtz frequency of 22.87 Hz in a box of 1.27 cu ft. of volume.
Thanks for the help Wayne.

massimo
