

---

Subject: Concrete walls

Posted by [Rockstar](#) on Sat, 26 Apr 2014 16:04:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

We want to set up a home theater in our basement. We have finished it off but we still have concrete walls. Will this make a difference with the sound quality? Should we do something with the walls?

---

---

Subject: Re: Concrete walls

Posted by [LoveJB](#) on Fri, 16 May 2014 22:21:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I would imagine that the concrete walls will produce a different sound. I don't know what you would do, besides insulate them and throw up some drywall. You might just have to give it a shot and see how it sounds.

---

---

Subject: Re: Concrete walls

Posted by [Wayne Parham](#) on Sat, 17 May 2014 05:41:49 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Concrete walls make room modes much more pronounced than rooms with less rigid walls. You'll want to add some damping, like panel absorbers, for best results.

---

---

Subject: Re: Concrete walls

Posted by [Round2](#) on Fri, 06 Jun 2014 10:17:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Concrete walls are not good for the overall sound in the room. I would put up sheets of drywall to help with the acoustics in the room and not to mention giving the room a finished look.

---

---

Subject: Re: Concrete walls

Posted by [MusicWife](#) on Thu, 04 Feb 2016 08:32:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Oh, interesting. We're having a new house built, and are having a room in the basement turned into a media room. The builder has given us about a million options as far as finishing it, for sound quality goes. Of course, they all come with a price, and some are quite hefty. Are there any things we absolutely MUST have? I think some of the stuff must just be builder padding. I'm sure they'll put it in, but probably aren't really necessary. Any recommendations, or advice would

---

be greatly appreciated.

---

---

Subject: Re: Concrete walls

Posted by [Wayne Parham](#) on Mon, 08 Feb 2016 19:48:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Most builders don't know anything about sound. It's just not what they do.

My suggestion is to read and understand room acoustics and then direct your builder with choices that make sense for you.

Usually, framed drywall construction is somewhat damped already, just by the nature of the materials and construction. But if you have concrete walls, then you'll need to apply damping of some sort, otherwise the whole room echoes like a shower stall. The best would be constrained layer, false walls or some other sort of panel absorbers for low frequencies combined with acoustic wedges for medium and high-frequency damping. Drapes can be used to cover the wedges for a more residential aesthetic, and they provide some HF damping of their own.

---