

---

Subject: AC/DC Electronics

Posted by [Manualblock](#) on Fri, 17 Dec 2004 23:08:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

In the spirit of education and electronics; is there a simple explanation of exactly how and why there can be a DC component riding on an AC waveform? Thanks, J.R.

---

---

Subject: Re: AC/DC Electronics

Posted by [Wayne Parham](#) on Sat, 18 Dec 2004 06:17:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Instead of having an AC signal with zero crossing at 0 volts, shift it to whatever the DC level is. That is a description of an AC signal riding on a DC one. If you think about it, there is always a DC component. Whatever the zero crossing average is, that's the DC value. If it is exactly the same as your reference, then you might consider it to have no DC component, or zero volts. But if you reference it to something else, there may be some DC offset.

---

---

Subject: Re: AC/DC Electronics

Posted by [Manualblock](#) on Sat, 18 Dec 2004 08:44:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

How do I know what the DC level is?

---

---

Subject: Re: AC/DC Electronics

Posted by [Wayne Parham](#) on Sat, 18 Dec 2004 12:42:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

With an oscilloscope, set the input for DC coupling. You'll see an offset, and that reflects the DC level. If all you have is a DVM, you could use a 1Kohm resistor in series and a large capacitor after that in shunt to filter out the AC. The DC level is all that will remain, so just measure it with the DC voltage setting on your meter.

---

---

Subject: Re: AC/DC Electronics

Posted by [Manualblock](#) on Sat, 18 Dec 2004 13:59:20 GMT

---

Excellent; thanks Wayne.

---