Subject: dummy impedance/power load to replace speaker being repaired?
Posted by doobya on Tue, 29 Jul 2008 01:35:54 GMT
View Forum Message <> Reply to Message

Hi,The woofer on one of my 3-way speakers just died, so I disconnected it and sent it in for repair.Meanwhile I set my amp balance 100% to the other channel and thus don't have stereo sound anymore.I am wondering if I can attach some kind of impedance load to the disconnected woofer cables, and hook that speaker up again. The idea is I will get somewhat stereo sound through the tweeter and medium while my woofer is in repair.My assumption is that the low-pass filter isn't designed to run without load on the output, and I don't want to damage it.The woofer is 8 ohms in impedance and 80W nominal power.tech specs:
http://www.forumcabasse.org/wiki/30BZ18Thanks for any pointers!

Subject: Re: dummy impedance/power load to replace speaker being repaired?
Posted by Wayne Parham on Tue, 29 Jul 2008 17:06:10 GMT
View Forum Message <> Reply to Message

This is a a good part for substituting as a test/dummy load. It also works great for Zobels.

Subject: Re: dummy impedance/power load to replace speaker being repaired?
Posted by doobya on Tue, 29 Jul 2008 17:41:15 GMT
View Forum Message <> Reply to Message

thanks!