

---

Subject: Yet Another HORNRESP Question....  
Posted by [wunhuanglo](#) on Fri, 02 Apr 2004 14:39:01 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

VRC - is that net (volume minus driver displacement) or gross? In other words does the program assume a rule-of-thumb driver displacement volume based on Sd? Thanks

---

---

Subject: Re: Yet Another HORNRESP Question....  
Posted by [Wayne Parham](#) on Fri, 02 Apr 2004 14:55:40 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

That's net. You must enter the actual throat chamber volume. This is usually the volume between the cone and the mounting plate for cone-driven horns. Also include the volume made from the cross-section area of the mounting plate and its thickness, although most times this is small enough it doesn't matter much.

---

---

Subject: Re: Subwoofer Horn  
Posted by [Mike.e](#) on Fri, 02 Apr 2004 15:49:35 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

isnt Vrc the volume of the REAR chamber not the front wayne?but the Vtc, of the front chamber ,thats what you described correctly?

---

---

Subject: Re: Subwoofer Horn  
Posted by [Wayne Parham](#) on Fri, 02 Apr 2004 16:12:23 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Of course, you're right Mike. Jeez, I don't know how I misread that. But the volume entered should still be NET actual volume, and the displacement from stuff inside the chamber (like the driver itself) should be removed.

---

---

Subject: Thanks guys!  
Posted by [wunhuanglo](#) on Fri, 02 Apr 2004 17:25:26 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I assumed as much, but I thought I'd make sure.Thanks again.

---