

---

Subject: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Peter Krojgaard](#) on Mon, 19 Mar 2007 10:55:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi, If the transition from a compression driver to a rectangular horn is less than optimal, where in the frequency band will this be most audible - and how? I ask because I use a pair of large rectangular 200 Hz mid/high horns for a pair of BMS 4592 ND drivers (I use this combo from 266 Hz and up). The throat transition is not a disaster, but it is not super smooth either, and I have some harshness in the treble (6-9kHz, I think) and wonder to what extent this harshness may be due to the non-optimal transition. Thanks! All the best Peter

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Wayne Parham](#) on Mon, 19 Mar 2007 15:13:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The closer to the throat entrance, the higher in frequency the effects will be.

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Peter Krojgaard](#) on Mon, 19 Mar 2007 16:53:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne, Thanks a lot for your reply! To be more specific: In my horns the first 3/4 of an inch (the "adapter") is not flared at all, but resembles a "tube" (I hope it is possible to visualize my description!). After that, the circular entry is slowly (over a distance of app. 2 inches) converted to the rectangular form of the exponential horn. This transition piece is fairly smooth, but not perfect. Given your expertise, do you find it likely that a "transition" as described above would (or could) cause harshness in the 6-9 kHz range (in my case, especially too pronounced s-sounds in female voices)? Thanks again Wayne! All the best Peter

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Wayne Parham](#) on Mon, 19 Mar 2007 22:02:39 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

set by the length of the adapter. This is particularly true if the interface isn't smooth, or if the flare boundary conditions.

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Cuppa Joe](#) on Tue, 20 Mar 2007 00:46:54 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I know that the BMS 2" coaxials have a little frequency spike just above the crossover point of 6.3kHz with their passive network. You might try an active crossover, if you're not using one already.

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Peter Krojgaard](#) on Tue, 20 Mar 2007 05:34:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne, Thanks a lot for your reply - helpful as always! Your reply makes a lot of sense, thanks! Regards Peter

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Peter Krojgaard](#) on Tue, 20 Mar 2007 05:37:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Cuppa Joe, Thanks a lot for your reply. At the time of writing I use a passive crossover between the BMS mid and the BMS tweeter. Actually I have dampened the tweeter just above 6K as you suggest. I already use an active filter between my bass horns and the BMS, and maybe an all active solution is the way to go with the BMS. Regards Peter

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [DMoore](#) on Tue, 20 Mar 2007 17:15:42 GMT

---

That is very true. I had a pair of the Edgar Tractrix 500Hz wood horns (square throat) that worked outstandingly on the midrange frequencies, but beamed horribly (excrusiatingly bad) on the high end with the BMS 4590 coax drivers. I should have known better, but it needed to be tried since I had them. DM

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Cuppa Joe](#) on Wed, 21 Mar 2007 01:50:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If you biamp your BMS mid/tweeter sections, cross just a WEE bit below the passive's crossover point (6kHz instead of 6.3kHz), and really be careful about how much power the tweeter gets! The slightly lower crossover helps to tame that peak at 7kHz.

---

---

Subject: LC Peaking

Posted by [Wayne Parham](#) on Wed, 21 Mar 2007 04:25:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yes, I think that might be caused by LC peaking in the crossover. When capacitance and inductance are in the circuit, a resonant condition is formed. Without the right amount of damping, it can cause peaking. The electrical properties of the driver (including the transformations of acoustic resistance/reactance into mechanical resistance/reactance and eventually into electrical impedance) come into play as well.

Some people, including even some well respected speaker designers, consider a loudspeaker to be resistive, and estimate it as such when doing calculations. It is particularly inappropriate for horns because they are 1/4 wave devices that have several impedance peaks near cutoff. Since this is where they are likely to be crossed-over, it is important to consider the impedance of the horn in the crossover region. Even though a horn approaches pure resistance, it only does this well into its passband and only if adequately sized. Many times, horns are undersized to meet specific design criteria and the crossover point is almost always low in the pasband, so the horn's complex impedance near the low-frequency crossover point must always be considered for best results.

Each year, I give a seminar called "Crossover Electronics 101" at the Lone Star Audiofest. The main emphasis of this seminar is to familiarize people with reactive circuits, to show exactly how peaking can (inadvertently) creep into a crossover design and to show how to damp the circuit properly to prevent it. I present a series of slides with schematics and response charts that show what each circuit does. Then we connect each circuit to a horn tweeter and play sound through it,

listening to each one to hear how they sound. I think it's interesting for people to actually hear what various levels of peaking sounds like, and to compare different circuit types.

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [Peter Krojgaard](#) on Wed, 21 Mar 2007 07:22:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Cuppa Joe, Thanks for your suggestion, I will consider going all active! Regards Peter

---

---

Subject: Re: LC Peaking

Posted by [randle](#) on Sun, 08 Apr 2007 03:06:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

So let me ask you a question. This is something that I have been wondering for a long time. Me as an artist, someone who creates music wants to know, when composing a track, beat, song. Do the instruments play a huge part in the the collaboration with how speakers work?

---

---

Subject: Re: LC Peaking

Posted by [Wayne Parham](#) on Sun, 08 Apr 2007 14:53:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

No, speakers are sound reproducers and should be as accurate as possible. They are to give the illusion that the instruments used are right there in the room with you, not add anything or take anything away. If you want to augment a certain track, instrument or music range, then you can use EQ to do it. But ideally, your speakers are capable of being sonically neutral.

---

---

Subject: Re: LC Peaking

Posted by [Cuppa Joe](#) on Sun, 08 Apr 2007 16:25:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If you play your guitar through a Celestion guitar speaker, sonically optimized for that instrument, it can sound great. However, if you record that guitar sound and play it back through the same

---

speaker, it will sound like ka-ka.

---

---

Subject: Re: LC Peaking

Posted by [randle](#) on Wed, 11 Apr 2007 15:18:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Now can you explain to me why that is?

---

---

Subject: Re: LC Peaking

Posted by [Cuppa Joe](#) on Thu, 12 Apr 2007 03:02:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It's related to Wayne's response above. A guitar speaker is made to PRODUCE a characteristic guitar sound. It will have colorations and range limitations which complement the instrument. If you mic the speaker and record your guitar sound, then play it back through some decent studio monitors, they will REPRODUCE your guitar sound accurately. If you playback the recording through your guitar speaker, it will again add its colorations and range limitations. You won't get your original guitar sound, and you're not likely to get something better, either. If you have the gear, this can be a fun experiment.

---

---

Subject: Re: Consequences of non-optimal throat transition in mid and high frequency horns

Posted by [randle](#) on Thu, 12 Apr 2007 23:12:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Can you elaborate on what you mean by an active crossover.

---