Subject: Driver alignment?
Posted by Tom R. on Tue, 23 May 2006 02:01:27 GMT
View Forum Message <> Reply to Message

I was reviewing a Focal driver (model 5K013L) specification sheet I hope to make a line array with, and in the alignment table under the SEALED CABINET: Vb(liters), I am wondering what "Rg": along the top (X direction) means. I understand what the vertical column (y direction) is, the alignment valves of .5, .577, .707What do these valves represent in that table:Rg: 0 Ohms,Rg: 0.2 Ohms,Rg: 0.4 OhmsRg: 0.6 OhmsRg: 0.8 Ohms Anybody?Tom R

Subject: Re: Driver alignment?
Posted by Tom R. on Mon, 29 May 2006 23:59:22 GMT
View Forum Message <> Reply to Message

From another contributor: the values from the table repesent the resistive value of inductors in series with the driver.