Subject: How to burn-in array speakers

Posted by mediafreak on Wed, 05 Nov 2008 10:04:26 GMT

View Forum Message <> Reply to Message

I am building array speakers with the Vifa PLW 14 5,25" woofers. I guess it would be best to burn-in the units before making the filters. Is it a usable idea just to use a net-transformator (50 or 60Hz.) with a sinus wave, where the units is outside the cabinet (less noise), or should it be white noise? is it possible to burn the units in outside the cabinet? Mediafreak

Subject: Re: How to burn-in array speakers

Posted by Wayne Parham on Wed, 05 Nov 2008 18:36:46 GMT

View Forum Message <> Reply to Message

I would prefer a little excursion, myself. Not anything close to x-max, but maybe 25% to 50%. A midbass sine wave is easier to cancel acoustically, running even numbers of drivers reverse connected. That way you don't have to hear them, at least not loudly.

Subject: Re: How to burn-in array speakers

Posted by mediafreak on Fri, 07 Nov 2008 13:35:09 GMT

View Forum Message <> Reply to Message

Thanks - I will try this one.mediafreak

Subject: Re: How to burn-in array speakers

Posted by FredT on Sat, 08 Nov 2008 14:35:12 GMT

View Forum Message <> Reply to Message

I'm just parroting what I've learned from others about this topic, but it's worthwhile to burn in woofers before measuring them because their TS parameters will change enough with use to effect the speaker's tuning. Danny Ritchie did some research on this topic, and here's the link to his conclusions.

GR Research: Driver Burn In Myths

Subject: Re: How to burn-in array speakers

## Posted by mediafreak on Mon, 10 Nov 2008 09:53:46 GMT

View Forum Message <> Reply to Message

nice link to Danny - I have already seen it.I am buying some NEO3 units from him to my LR.There is a big difference among the units concerning the impact of the burn in (wake up)torture. Mediafreak