
Subject: 6v6v6

Posted by [Manualblock](#) on Sat, 12 Feb 2005 13:11:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

So is the 100ma rating on the power trans adequate to run PP 6v6's?

Subject: Re: 6v6v6

Posted by [Damir](#) on Sat, 12 Feb 2005 19:45:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

Yes, but...:-) See some tube data for 6V6 and EL84 (similarly). With "standing current" of about 30-40 mA per tube, and U_a of 250-300V we can expect about 4-5 W in PP triode A class, or about double in UL. Pentode and AB class ~15W or little more. With max. power, our 60-80 mA "standing current" would rise very close to the 100mA, and better use "economical" driver tube that work with only a few mA...

Subject: 6v6x2

Posted by [PakProtector](#) on Mon, 14 Feb 2005 00:45:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hey-Hey!!!,I think the L-C filter would gain us something, especially if a conservative rectifier was used. 400 volts @ 100 mA is 40 watts. 3A of 6.3 and 5 VAC is about 30 watts. 70VA core will have more to give the HV is full use of the heater taps is not made. It will not be all that close I suspect.Class A bias with 6V6's in U-L and using the middle taps and a 6BK7B driver pair(figure ~6 mA for that stage or so) will give B+ of ~240VDC. No biggie....regards,Douglas
