

---

Subject: LEDs light - can I assume CCS is wires properly?

Posted by [colinhester](#) on Tue, 01 Mar 2005 01:13:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Got everything done except for the signal path. Fired it up and all the tubes glow and the 4 LEDs shine like the stars. Can I assume the CCS is properly wired (not biased yet)? If so I got 4 more wires to go.....Colin

---

Subject: Almost certainly

Posted by [PakProtector](#) on Tue, 01 Mar 2005 01:44:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

sounds good to me so far. I would suggest putting a 10R resistor in series with the B+ lead to each CCS to measure the current. You don't want to run the LED's over current. Or you could clip lead in the battery and measuring equipment to determine regulated current amount. Do measure before running extensively. You could get fairly close by adjusting current to give ~130 volts on the plate. With the 2x LED bias, it should be between 10 and 15 mA which is quite LED-safe. regards, Douglas

---

Subject: Dead on 130V and stupid question

Posted by [colinhester](#) on Tue, 01 Mar 2005 02:07:28 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Got the bias set to 130 VDC with just a couple of turns of R3. Here's a really stupid question: To measure current on a DVM, does the meter need to be in series with what you want to measure? I clip the leads to the plate and ground and get 130 V no problem. If I switch the meter to measure current I get zero....Colin

---

Subject: ummmmm

Posted by [PakProtector](#) on Tue, 01 Mar 2005 02:13:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Well, I would say that you need the ammeter in series. I would suggest looking for a blown fuse in your meter. The meter should offer a near-zero impedance on the current setting. However, we are working downstream of the CCS so it may never get a current overload. I must try this on my lineage. All the current ought to pass through the meter ( the LED's will go out ) instead of the valve. My first suspicion is that you have blown the meter's some point. Don't feel silly about that. I

buy those .25 A fuses in bulk...regards,Douglas

---

---

Subject: Yeap, blown fuse

Posted by [colinhester](#) on Tue, 01 Mar 2005 02:32:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Fuse in the DVM was gone. I remeasured from plate to ground and adjusted to 15mA; the voltage was 100VDC both channels. When adjusted to 130VDC as before the current was around 50mA. Staying at 15mA and 100VDC. And yes, the LEDs went out when measuring the current this time. Thanks a bunch.....Colin

---

---

Subject: Re: Yeap, blown fuse

Posted by [cheetah](#) on Tue, 01 Mar 2005 03:26:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Why can't you put a 1 ohm resistor between R3 and the plate? Then measuring across this resistor,  $15mV = 15mA$ . Impact on circuit should be nil. Joe

---

---

Subject: Re: Yeap, blown fuse

Posted by [PakProtector](#) on Tue, 01 Mar 2005 11:16:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

actually, I like Colin's method. Never thought of doing it that way. There is no danger, save for heat generation, as the CCS is dropping all of B+. For short period of time, it shouldn't pose a problem. Just be sure you don't try this from the mu output, as damage could be done to the mosfets, and there is no way to get an real measurement w/o including R3. I am going to try this on my valve pre-where I can't test w/ a 9V out of circuit. Thanks for showing me this method. regards, Douglas

---