
Subject: throw another preamp on the fire, boys!
Posted by [Forty2wo](#) on Mon, 14 Mar 2005 01:03:12 GMT
[View Forum Message](#) <> [Reply to Message](#)

Just kidding. I got Gunievere pretty much sorted out. First the major hum, while I was in there adding the grid stoppers I killed one of the CCS's. My guess is ESD. Thank you Colin for the spares! Next; back were I started, hum that increases with volume then stops at max. After a bit of poking around I found that in my case, the body of the Radio Shzck pot needed to be grounded. Dispite the fact that can find no leakage even with my best meter. Go figure. Now it is pretty quiet. There is still some hum with volume but considering the amount of gain and the fact I removed the sheilding troble shooting the pot, it will do untill I change to a lower gain tube...John

Subject: Re: throw another preamp on the fire, boys!
Posted by [Manualblock](#) on Mon, 14 Mar 2005 01:13:36 GMT
[View Forum Message](#) <> [Reply to Message](#)

Glad to see you up again. Can I ask which tube you are looking at and if there are any circuit changes neccessary to utilise that tube?

Subject: Re: throw another preamp on the fire, boys!
Posted by [Forty2wo](#) on Mon, 14 Mar 2005 02:22:02 GMT
[View Forum Message](#) <> [Reply to Message](#)

I will probably go with the 12b4 as I have a pair. To run them in Guinevere you need a second socket is they are single triode's. Add 1 or 2 more LED's to the string and crank up the current a bit, that's it. I bet there are some folkes more familiar with the world of 9 pin tubes, that can recomend a low mu twin that you can pretty much pop right in...John

Subject: Grid stoppers
Posted by [colinhester](#) on Mon, 14 Mar 2005 02:45:27 GMT
[View Forum Message](#) <> [Reply to Message](#)

I'm glad to hear you tracked down the hum. I was hoping this was the problem and not a poorly wound Tx. I'll ground my pot tonight. I thought I had the issue of isolation between the chassis and signal ground resolved, but there is still continuity. I thought the volume pot was the culprit, since I could lift it off the chassis and get infinite reistance. I need to see if a wire strand is causing the problem. I'm really surprised that ESD killed the 2540 that easily. Mine took a direct

hit when checking voltages. Let's just say I about wet myself - didn't shock me, but did get my attention. Do you need a couple of 2540s as spares? I could drop a couple more in the mail if you would like. Are you going to do the amps next. I'm really excited. This whole process has been much more than I could have imagined.....Colin

Subject: lower mu...

Posted by [PakProtector](#) on Mon, 14 Mar 2005 11:05:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

Nope, you have it. A few more LED's will be all. More current is a 'tweak' level of change. 6 or so LED's and another socket will be all that is required. You'll be pulling a little bit more heater current. Still going to be 12.6, but at 0.6 A instead of 0.5 A. Some tweaking of the R's in filament supply might be needed if you want exactly 12.6. 12-13 ought to be fine IMO...The 12B4's are mu 6.5 and until you increase heater current or get octal valves, it is the best. Maybe the best without caveats. regards,Douglas

Subject: Re: Grid stoppers

Posted by [Forty2wo](#) on Tue, 15 Mar 2005 04:15:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Colin, As to the hum. there is something funky about those pots. this is not the second or third time they have thrown a curve. I ended up tying my chase ground to signal ground. With my high tech chase covered with space age teflon. the pot may or may have not had contact with the steel. the connection didn't increase the noise so I left it. try a clip lead and see. ESD is probably what got the fets. with this cold dry air, zap. the amp was unplugged for a full day PS down to 0 on its own. Fet's are sensitive this is one reason you see zener clamping diodes on some CCS circuits I would like to get another set. let me pay for them this time as you were kind enough to get them. On the amp front I just converted my JE labs/ FI 300b to WE type 91 and I like it a lot. I have a DRD project in the pipeline. still collecting parts. I am going to follow along and see. I have some 6a5's I want to use and I want to fool with a transformer phase splitter and parts on hand. But who knows, Douglas is a master of push pull amps and I want to see what kind of transformers are brewing...John

Subject: Re: Grid stoppers

Posted by [colinhester](#) on Wed, 16 Mar 2005 04:14:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

I think you're right about those RS pots. I have all the noise ghosts gone, except when I touch the

voulme pot. I expect this since it is not grounded, but I can put slight sideways pressure on the volume pot's shaft and get a considerable change in noise level. I really think I'm going with the dual 12B4 (?) rectifiers and a stepped attenuator. No need screwing around at this point. I'll try and get another set on 2540s out to you this week. No need to pay. Your help has been more than enough. Thank you. What is a DRD? I'm really nervous about the amps. This preamp was my first serious build using only a schematic. I have more confidence in my abilities, but there is still a lifetime of techniques to learn. I can tell you one thing, I will NEVER build from a kit again. The high I got when Guinevere came to life was worth all the troubles.....Colin

Subject: Re: Grid stoppers

Posted by [Forty2wo](#) on Wed, 16 Mar 2005 22:20:59 GMT

[View Forum Message](#) <> [Reply to Message](#)

Glad to hear you got the noise. Thanks for the 2540's I am happy to help if I can. DRD is direct reactance drive, this is the type of amp taht Ron Welborne has. Look here
<http://www.electra-print.com/circuits.html>...John
<http://www.electra-print.com/circuits.html>
