

---

Subject: Bleeder Resistors

Posted by [Shane](#) on Tue, 17 Oct 2006 03:34:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I know this has been covered about 1000 times (maybe more)and I posted this over on the Bottlehead site as well, but just wanting to see if using these particular clips with a bleeder resistor would be the way to go to discharge caps? Just solder in the resistor after cutting the lead wire and heatshrinking everything 2-3 times over the resistor leads and edge of the resistor? Oh, and don't touch the resistor or let it touch other things, I'm thinking, as the cap discharges.

Clip Leads

---

---

Subject: Re: Bleeder Resistors

Posted by [Wayne Parham](#) on Tue, 17 Oct 2006 14:30:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Those look like the clips often used on oscilloscope and multimeters. Should work pretty well. One thing to think about though: If the voltage is high so that there is a bit of arcing as the connection is made, the clip leads might erode over time. There's not a lot of meat on clips like this. Alligator clips are more sizeable, but then again, that means it would be harder to get them connected in tight spaces.

---