

---

Subject: Where art thou Woodworker

Posted by [dbeardsl](#) on Sun, 24 Mar 2002 07:46:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Question for all ye woodworkers, well anybody who builds there own cabinets. What are some different methods you have used for joints? I'm thinking either a double dado or single dado. double dado \_\_\_\_\_|\_\_\_\_\_|xx|\_\_\_\_\_|xxxx|xxxx|xxxx|single dado \_\_\_\_\_|\_\_\_\_\_|xxxx|\_\_\_\_\_|xxxx|xxxx|xxxx|Got an interesting idea though. Use dowels at a 45 degree angle, coming all the way out both surfaces of the cabinet, out just far enough not to actually go into the cabinet. Then cut em off and sand flat.. Would definately help the joint, might be hard to drill at a 45, might look neato though.

---

Subject: Re: some idea's

Posted by [bmar](#) on Sun, 24 Mar 2002 14:28:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi, There are about as many different joint as there are different speaker drivers! some fundamentally better than other and some are just preference! If you were to invert your your double rabbit joint, it would be a little stronger. Since the speaker box will not be seen from the inside and has no conflicting internal parts. I prefer to use and inside glue block that is screwed into the corners (not nailed). Your idea for corner dowels is similar to "through dovetails" and would look great! you would need a jig with a drill bushing that you could clamp onto the corner of the box, and a very sharp brad point drill. maybe someone with more veneer experiance would have an idea. I would probably make one fixture that was the length of the corner. this would have all the dowel hole in it, and able to take different drill bushings. this way you could drill one series of holes undersize. replace all the drill bushings, and drill your final sized hole. this would give you a clean hole on the final pass. a lot of work huh? cool design! have fun. Bill

---

Subject: Re: some idea's - best woods for cleats and on-edge braces?

Posted by [freddyi](#) on Sun, 24 Mar 2002 16:09:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Bill! I've always used poplar for cleating - a buddy of mine put together a box for me using the

worst 3/4" square pine I've seen - almost all split :~( need to do a cleat replacement.. couldn't get him to pick up my poplar boards to rip - anyhow, what woods do you prefer for cleating and on-edge braces? (other than plywood/MDF)also - would you make cleats 3/4" square or a bit larger? ( got some big boxes ahead)Freddy

---

Subject: Re: some idea's - best woods for cleats and on-edge braces?

Posted by [bmar](#) on Sun, 24 Mar 2002 16:43:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Freddy,I have always made the cleat from the same material the carcass is made from. This will keep the wood all of the same stability. In the case of veneered plywood. I have used both maple and oak since they are strong and the screw will have less tendency to work its way into the cleat and becoming loose. I like to make the cleats 1" or 3/4 x 1 anyway. I have not tried it yet, but I hear some people like the Gorilla Glue. supposed to be good for end grains in corner joints and the like. I think a real problem is you need about 5 years of expanding and contracting with the season changes to be able to see how a joint is going to hold up. To offer a suggestion of yet even more work! put two coats of finish on the inside of the box too. Bill

---

Subject: Some more ideas

Posted by [BillEpstein](#) on Sun, 24 Mar 2002 19:44:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

Bill's right on the money, again, about reversing what you call a dado which is actually just a rabbeted joint. Reversing your single version is called a "housing joint" and is very strong. The British are in love with them! Also easy to cut as only one set-up is required on the tablesaw for both cuts. The dowels would look nice and resist racking of the carcass but do little to strengthen it. Visit some router accessory sites and look at bits that are designed to create an expanded gluing surface for joining panels. They usually cut a 45 degree miter at the same time they put a rabbet or 2 in the joint. Very strong and accurate. Look for links on [finewoodworking.com](#). Oh yes, you could also miter the edges of the panels, which would hide the plywood edges and then cut kerfs along the entire length to insert splines. Accurately cut kerfs would locate the panels for glue-up and make the joint very strong as the splines are all long grain. 1/8" kerf - 1/8" spline. A variation on that would be using biscuits instead of splines. Good excuse to acquire another tool.

Go to Borders, order a coffee and spend an hour in the woodworking books section. Two hobbies for the price of three!

---

Subject: Re: some idea's  
Posted by [dbeardsl](#) on Mon, 25 Mar 2002 22:44:03 GMT  
[View Forum Message](#) <> [Reply to Message](#)

Think it would be alright to use that inverted dado, or rabbit joint, but in the upper piece only do 1 cut, leaves a little more meat on the board and 1 less cut to do. Like

This: \_\_\_\_\_|xxxxx|xxxxxx\_\_\_\_|xxxxxe|ooo||\_\_\_\_\_|ooo|\_\_\_\_\_  
\_\_\_\_\_|ooooooooo||ooooooooo||ooooooooo||ooooooooo|Also, with those screws from the inside, would you recommend screwing them while the glue was drying or afterward?

---

Subject: Re: some idea's  
Posted by [bmar](#) on Mon, 25 Mar 2002 23:29:44 GMT  
[View Forum Message](#) <> [Reply to Message](#)

your design should work just fine. glue up the all 4 pieces clamp from top to bottom, 2 or 3 clamps per side. make sure the box is square. measure corner to corner and tweak the angle of the clamps until you get the same measurement. glue and screw your corner blocks in now, don't wait! check for square again. tips: pre drill and countersink all holes in the blocks. the screw should slide right through the block. remove any chips/burrs from backside. put all screws into the side first ( the piece with the "o") then screw into the top or bottom, the screws will work with the clamps. you'll need a slower setting glue like a liquid hide or a plastic resin. yellow glue will set too fast for you. make sure your corner blocks are shorter than the sides. you still need the front and back to drop in. other thoughts: you could use this joint on the front and back too. in which case i would assemble the top and two sides with the corner blocks. slide the front and back panels in with glue. then put the bottom on. now you can reach into the woofer hole to get at the bottom glue blocks. now you have a great reason to get more clamps!

---

Subject: Re: Where art thou Woodworker  
Posted by [Erik from Holland](#) on Wed, 27 Mar 2002 09:46:50 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I just finished a set with what you call a double-dado joint. But with an extra!! Soon i will post a few pics of my projects on this site, so keep looking for messages from "Erik from Holland" ByeBye!

---

Subject: drop testing enclosures  
Posted by [Sam P.](#) on Wed, 27 Mar 2002 14:27:27 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Can we get Adam to build a few cubes, perhaps 1 cu.ft. each, where the panels are either plain butt joints or dadoed. Glue only and screwed/glued too. Then fling them up high, and see if the extra "strength" helps when they come to a sudden stop at ground level. Sam

---

Subject: heh  
Posted by [dbeardsl](#) on Wed, 27 Mar 2002 17:08:39 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

My guess is they would both do well with 1 cuft and no heavy driver on one panel. Get to a certain point and the glued one would break apart while the screwed one would stay together but become increasingly deformed. oooh tilted parallelogram cabinets :-)) I've done some testing myself, and steel framed VCR's that frustrate you for days then won't play anymore fair very well on drop tests. You can't throw it high enough, requiring the use of simulated dropping technology(sledgehammer).

---

Subject: Thanks

Posted by [dbeardsl](#) on Wed, 27 Mar 2002 17:11:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yeah, I'll definately need more clamps... :-))I'll proolly have a few more questions come construction time.Thanks!