
Subject: mdf cabinet assembly question

Posted by [ray99](#) on Thu, 16 May 2002 11:09:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi. After all pieces are cut, can anyone write a couple of sentences about the technique of how to glue all pieces together. I think I have to use butt joints because rabbet etc is over my head. Are the front and rear pieces glued to the edges of the sides or do they fit inside of the side pieces ? Do you glue one joint at a time or all pieces at once? Thank so much for your help. Ray.

Subject: not sure about the other guys

Posted by [Sam P.](#) on Thu, 16 May 2002 11:32:39 GMT

[View Forum Message](#) <> [Reply to Message](#)

but I usually glue the top/bottom/sides together first, forming a rectangular "skeleton". All cut outs and routing is done to the front baffle, which is attached next. Install your port tube(s). The rear wall is attached last, I used to make them removeable, but when you have a 14 inch "access hole" in front, nonremovable is easier to insure a good seal. 1x2's are glued horizontally in several places to attach the fiberglass lining and space it away from the walls slightly. If you only have a jig saw, once the rectangular frame is made, lay it on the plywood and trace out the exact dimensions of your front/rear panels, then cut as close, but OUTSIDE, the lines as possible, to avoid excess sanding. The 4 Pi Pro's I built in this manner were all plain glued butt joints, done with care. I think leaving out the screws joining the panel edges MIGHT reduce the chance of splitting later, since stress at the screw holes is avoided. For sure you save the time otherwise spent drilling/screwing and applying filler over the heads. For a single project, the "drill/glue/screw method" will be cheaper than buying the 6 clamps or so I needed. Be sure to invest in the proper pilot hole drill for the screws you choose. Good Luck! Sam

Subject: Re: mdf cabinet assembly question

Posted by [SteveBrown](#) on Thu, 16 May 2002 12:43:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

On MDF I have had good success using butt joints and just glue - no screws. I like to assemble the front, sides, top and bottom all at once. It is a bit awkward and you will need some clamps. Using screws can help this - it eliminates the need for clamps. The reason I do it this way is that I get a better fit around the front baffle. Also, on MDF if your edges are a bit proud you can use a flush trimming bit on a router to just wiz them down to a nice flat finish with the other panels. Steve

Subject: flush trimming router bit
Posted by [Sam P.](#) on Thu, 16 May 2002 13:05:13 GMT
[View Forum Message](#) <> [Reply to Message](#)

would have saved me a lot of sanding. That tip was worth its weight in gold. Thanks, Sam I am on my way to the hardware store right now!!!

Subject: cab assy
Posted by [Paul C.](#) on Thu, 16 May 2002 19:05:23 GMT
[View Forum Message](#) <> [Reply to Message](#)

For PA and MI spkrs, I make my cabinets so there is a 2" setback from the front edge to the baffle. This provides protection to the drivers. Of course, for a Pi style folded horn, this would not be necessary, nor with a spkr for home use. With ply cabinets, I use small finishing nails or brads to tack the spkr together until the glue dries. Screws are really unnecessary. The important thing is accurate, tight fit. For MDF, the screws and glue may be better. I glue all sides and front and rear... all access is done through the woofer hole. To glue the crossover components... E6000 glue, Alene's 7800, or Goop Automotive Adhesive and Sealant. These are all the same, which are "SBR" adhesives. That is Styrene Butadyene Rubber. It dries clear, and is very, very slightly flexible. It bonds dissimilar materials very well. I have not had a coil come loose yet with this stuff. Pre-drill all holes. The screws will hold well without breaking up the material around it, and thus, actually a better hold. Woofers MUST have T-nuts behind them. Screwing into the baffle only is OK, but only with light drivers. Heavy pro drivers as used for Pi Spkrs, wood screws only will not do.

Subject: Re: not sure about the other guys
Posted by [RJW](#) on Thu, 16 May 2002 20:45:39 GMT
[View Forum Message](#) <> [Reply to Message](#)

Use self tapping drywall screws. Ron

Subject: thanks for the responses (NT)
Posted by [ray99](#) on Thu, 16 May 2002 21:44:19 GMT
[View Forum Message](#) <> [Reply to Message](#)

Subject: Black pan screws for mounting small drivers
Posted by [Wayne Parham](#) on Fri, 17 May 2002 17:07:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

I agree with you. I'm not really talking about cabinet construction but I like using these screws for mounting small and medium format drivers to the baffle. For that purpose, A pan screw as used for drywall is perfect. I used to hand paint the screws black, but now I use the 1" long #8 pan screws shown below, and get them from www.idxmart.com, part number 1F943-26637. Fasteners: US Standard: Steel: Screws, Wood, Pan, Particle Board, Phillips, Type A Point, Black Finish Seller: LGI Part Number: 1F943-26637 Package Size: 100 Diameter: #8 Length: 1

Subject: Re: Black pan screws for mounting small drivers
Posted by [RJW](#) on Mon, 20 May 2002 22:19:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

Thanks for the cool link.c':^)