

---

Subject: Impedance peak

Posted by [Pilkar](#) on Wed, 19 Feb 2003 17:05:49 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi everyone! I was looking the datasheet of the driver i will use, and it has a response graph were it is shown coupled to the horn i will use (lucky me). There is an impedance peak of 13ohms at around 900-950Hz. Since i will be crossing at 800Hz i thought there maybe a problem, like a shift in the crossover frequency. If that is the case, what should i do? Recalculate the crossover components for a 10-13 ohm load? Well, thats all for now! Thank you for your help!

---

Subject: Re: Impedance peak

Posted by [Wayne Parham](#) on Wed, 19 Feb 2003 17:44:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

An impedance peak of 13 ohms isn't terribly high, and is expected from a horn. There will be a few peaks near the flare frequency and its harmonics. There are also sometimes peaks caused by diaphragm mechanical resonance below the flare frequency, where the horn cannot load the diaphragm. To tame these peaks, and electrically mmatch the driver better with the crossover, I

information.

---

Subject: Re: Impedance peak

Posted by [Pilkar](#) on Wed, 19 Feb 2003 20:51:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thank you very much!