
Subject: Tractrix Horn Loading

Posted by [Adrian Mack](#) on Mon, 07 Jul 2003 00:38:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi everyone, So many people say tractrix horns don't load properly down to their flare frequency, and that they only start properly from about an octave above the horn's flare frequency. I've done some modeling in Hornresp, and found this statement to be not always the case. I've had some times where indeed it showed on the SPL curve that it doesn't go flat down to its flare frequency at all. But I've also found some tractrix horns that DO load right down to their flare frequency, according to hornresp. The Eminence Alpha 6 in a tractrix horn with flare freq of 242Hz, 26cm² throat and 1600cm² mouth (40cm long horn) does show it flat all the way down to 242Hz, which is its flare frequency. So would it be able to be used down to its flare frequency because it's flat all the way down to that? Or should I still follow the "rule" about tractrix horns not loading down to their flare frequency? Thanks! Adrian

Subject: Re: Tractrix Horn Loading

Posted by [Bill Martinelli](#) on Mon, 07 Jul 2003 00:52:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

You might find that even if the tractrix horn loads the driver down to cutoff that the throat distortion will increase at near cutoff frequencies. If this happens you will be unhappy. Every style horn will work better with different drivers but you won't know for sure until you build it and test it. Bill

Subject: Peaking in the bottom octave

Posted by [Wayne Parham](#) on Mon, 07 Jul 2003 01:21:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

You undoubtedly have some peaking in the horn design you are talking about that has increased output near the cutoff frequency. I often build conical horns with this same sort of response, so I'm not against this practice. But the fact is that the acoustic loading of tractrix and conical horns becomes less resistive at the flare frequency than it is further up, and this translates to lowered efficiency. A bump in the bottom octave from resonant peaking can be used to raise output instead.