

---

Subject: Used JBL 2426J in PI?

Posted by [GarMan](#) on Thu, 15 Jan 2004 17:10:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Is there anything I should be aware of when buying a set of used JBL 2426? I found a pro-systems place in town that's selling used units for a very good price. Also, the units that are available are the 2426J, 16 ohm versions. Are these usable in the 4PI configuration? X-over values would probably need to be adjusted.thanks,Gar.

---

---

Subject: Also want to know about 2370A Flare

Posted by [GarMan](#) on Thu, 15 Jan 2004 18:24:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Forgot to ask. Is there a substantial difference between the Eminence H290 flare and JBL's 2370A? Both are 90x40 and are designed to accept 1" throats. Is \$100 USD a good deal for a used pair of the JBLs? This would still be \$40 more than a new pair of H290.thanks,gar.

---

---

Subject: Re: Also want to know about 2370A Flare

Posted by [Wayne Parham](#) on Thu, 15 Jan 2004 20:58:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Used 2426's can sometimes have damaged or second-source diaphragms. You can use 16 ohm versions, although as you've noted, the crossover was designed for 8 ohm devices. We discussed the values here, so you might try a search. I'll rummage around and see if I can find this information too. As for the horn flare, the H290 is much smaller and shouldn't be used below 1kHz. I'd keep 'em above 1.2kHz, which is OK since the PSD2002 really needs to be crossed higher too. The JBL 2370 is a much larger horn and can be used down to 800Hz.

---

---

Subject: 16 ohm vs 8 ohm drivers

Posted by [GarMan](#) on Thu, 15 Jan 2004 21:26:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I did a quick search and I think I can gather enough information on XO values if I decide to go for the 16 ohm drivers. However, wouldn't mind if I can be briefed on the advantages or disadvantages of using 16 ohms vs 8 ohms. Isn't a higher nominal impedance desirable for tube amps?Gar.

---

---

Subject: Re: 16 ohm vs 8 ohm drivers

Posted by [Wayne Parham](#) on Thu, 15 Jan 2004 22:38:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Honestly - It's best to model the circuit in Spice. Most online documents about crossovers and the difference between 8 and 16 ohm drivers are going to talk about the crossovers as if the load were resistive. They may mention a Zobel, which would then make the load impedance act more

rising response at higher frequencies. It does this by using the voice coil reactance as part of the filter. So model the circuit with Spice to determine your values of R1, R2 and C1 when using a 16

---

Subject: Re: 16 ohm vs 8 ohm drivers

Posted by [GarMan](#) on Fri, 16 Jan 2004 03:25:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Wayne, I did a search under the H.Eff Speaker forum at the "other place" and found your post about 8 ohm vs 16 ohm speakers, and the need to match the impedance tap of the output transformer for maximum power transfer. Seems to make sense. However, my question now is, if the two drivers in a 2-way are connected in parallel, wouldn't you need two 16 ohm drivers to build an 8 ohm speaker?Gar.

---

Subject: Re: 16 ohm vs 8 ohm drivers

Posted by [Wayne Parham](#) on Fri, 16 Jan 2004 03:58:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

In a loudspeaker, the crossover prevents adjacent subsystems from being on-line at the same time. When a driver is making sound, it is being presented as a load to the amplifier. But when it isn't, the impedance of that leg of the circuit is very high, approaching an open circuit. The idea is that only the driver playing presents a load, and in the overlap region where both adjacent subsystems are transitioning, they both present a partial, medium-impedance load. So the overall impedance curve is rarely flat, but it does approach the advertised impedance in most cases.

---