

---

Subject: pro four Pi plans please  
Posted by [andreas paulsen](#) on Mon, 16 May 2005 09:08:12 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne Could you send me the four Pi plans please ?Cheersandreas

---

---

Subject: You've got mail!  
Posted by [Wayne Parham](#) on Mon, 16 May 2005 10:58:57 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

---

Subject: Re: You've got mail!  
Posted by [andreas paulsen](#) on Mon, 16 May 2005 17:22:19 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

ThanksThe box dimensions you're giving, does that include the loss of bracing the cabinet with a resonable amount of 1x2" lumber?What is the total volume displaced by the tweeter horn ? - I plan to use my philips ribbons instead (with active crossover) as I have the parts already. Might just use the liberated space for extra bracing.CheersAndreas

---

---

Subject: Calculating displacement volume with a composite of primitive shapes  
Posted by [Wayne Parham](#) on Tue, 17 May 2005 00:03:33 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Check out the program called volume.exe in the PiAlign distribution file. I don't recall the volume of the tweeter and horn, but you can easily get a good estimate by calculating it as a composite of primitive shapes. For example, a compression driver or speaker magnet can be calculated as a cylinder, a speaker cone as a cone and a horn as a wedge or pyramid.

---

---

Subject: Re: Calculating displacement volume with a composite of primitive shapes  
Posted by [andreas paulsen](#) on Tue, 17 May 2005 06:48:56 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

OK - I'll just do it by hand with my trusting old HP calculator - I'll check out volume.exe though. How much bracing is already calculated into the volume of the box? Cheers andreas

---

---

Subject: braces

Posted by [andreas paulsen](#) on Tue, 17 May 2005 07:33:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Well - after reading a massive amount of old threads it seems that pro-four Pi's are constructed without braces as the cabinet is small and filled with stuff:). I might brace it anyway. Cheers Andreas

---

---

Subject: removable baffle

Posted by [andreas paulsen](#) on Thu, 19 May 2005 18:59:03 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Do you suggest making the baffle removable, to be able to tune the port Or should I just biscuit and glue it all together and count on the tuning to be on spot? Any benefits of making the baffle 1.5" thick? I might just do it anyway to be able to flush mount the woofer. Take care andreas

---

---

Subject: Re: removable baffle

Posted by [Wayne Parham](#) on Thu, 19 May 2005 19:35:41 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I like to avoid removable baffles where possible. They're difficult to brace, and even where bracing isn't required, they tend to reduce strength as compared with a permanently fixed panel.

---

---

Subject: building

Posted by [andreas paulsen](#) on Thu, 26 May 2005 13:33:52 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi all The quasi pro fours are coming along nicely - made in 3/4 mdf and biscuit jointed. Bracing by a liberal amount of 1x2 and 2x4 pine lumber I found littered on the street in addition to a window brace above the woofer cutout. Second cabinet is in glueup while bracing the first. Need to

cut and route the baffles and glue them on.Cheersandreas--

---

---

Subject: Re: building

Posted by [andreas paulsen](#) on Sat, 04 Jun 2005 05:19:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hmm, just routed the woofer cutout 1 cm to large -- bugger /andreas

---

---

Subject: Re: building

Posted by [Wayne Parham](#) on Sat, 04 Jun 2005 05:26:41 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Ouch! Bummer! Maybe you can glue in a piece of wood, recut and re-route.

---